

NuVIEW Installation Instructions

Installation of Navitar/ NuView Series 374 lens on Eiki model LC-X6 & LC-SX6 projectors.

TOOLS REQUIRED: PHILLIPS HEAD SCREWDRIVER

Disassembly:

1. Disconnect unit from power source.
2. Remove front cover by removing 2 Phillips screws from bottom of lower cover. Remove 4 remaining Phillips screws from the top cover (2 on top of cover, 2 more near lower portion of top cover)

Assembly:

1. Separate your Navitar lens and adapter by gently rotating the lens counterclockwise while holding the adapter. **DO NOT** place undo pressure on the lens to separate as this may result in damage to the nylon drive pin.
2. Insert the keyed portion of the adapter ring into the projector with the up label in the up position and rotate the lens lock lever downward while squeezing together.
3. Replace the front cover of the projector removed in step 1, above.
4. Reinstall the Navitar lens into the adapter by turning clockwise into the adapter.
5. To focus, gently twist the front of the lens. To zoom, loosen thumbscrew and twist the knurled zoom ring. Re-tighten thumbscrew. **CAUTION:** When focusing, be sure not to twist lens completely out of the adapter!

Navitar, Inc.
200 Commerce Drive
Rochester, New York
14623

Phone
585.359.4000
800.828.6778

Fax
585.359.4999

navitar.com
info@navitar.com