

NuVIEW Installation Instructions

Installation of Navitar/NuView Series 606 lens on Epson PowerLite 7800p, 7850p, 7900 & 7950 Projectors

TOOLS REQUIRED: PHILLIPS HEAD SCREWDRIVER, 9/64" ALLEN WRENCH

Disassembly:

1. Disconnect the unit from the power source and place projector with the bottom facing up. Remove one (1) Phillips head screw holding the lens cover of the projector in place. Remove the cover and set aside for reinstallation.
2. Remove four (4) Phillips head screws holding prime lens in place and remove the prime lens.

Assembly:

1. Ensure that your Navitar lens and its adapter are separate. (If you are working with a MCZ275, separate the adapter by removing the two (2) Allen head cap screws and setting them aside.) Using the four (4) Phillips head screws removed in (2) above, install the adapter correct side up into the projector. Insert lens thru the front opening of the projector and position the two tapped holes in the lens housing with the two holes in the top of the adapter. Secure the lens in the adapter using the cap screws making sure the lens is aligned in the adapter.
2. Replace the lens cover of the projector removed in step 1, above.
3. To focus, gently twist the front of lens. To zoom, loosen thumbscrew and twist knurled ring (zoom lenses only, of course). Re-tighten thumbscrew. CAUTION: Do not twist entire lens out of adapter!

On MCZ275 models, twist the knurled inner ring to the desired zoom position and twist the knurled outer ring to focus the lens.

Navitar, Inc.
200 Commerce Drive
Rochester, New York
14623

Phone
585.359.4000
800.828.6778

Fax
585.359.4999

navitar.com
info@navitar.com