



Lifetime Warranty

To register this product go to:
www.presentation.navitar.com/warranty.cfm

NuVIEW Installation Instructions

Installation of Navitar NuView Series 370 lenses on Christie LX65 & LX100, LX120, L6 Roadrunner & L8 Roadrunner projectors.

TOOLS REQUIRED: PHILLIPS HEAD SCREWDRIVER

1. Ensure projector power cord is disconnected.
2. Remove front cover by taking 2 Phillips screws from top cover then lifting up while applying pressure to front of cover.
3. Insert the keyed portion of the adapter ring into the projector and rotate the lens lock lever downward while squeezing together.
4. Replace the front cover of the projector removed in step 1, above.
5. To focus, gently twist the front of lens. To zoom, loosen thumbscrew and twist knurled ring (zoom lenses only, of course). Re-tighten thumbscrew. CAUTION: Do not twist entire lens out of adapter!

Navitar, Inc.
200 Commerce Drive
Rochester, New York
14623

Phone
585.359.4000
800.828.6778

Fax
585.359.4999

navitar.com
info@navitar.com