

NuVIEW Installation Instructions

Installation of Navitar/NuView Series 594 lens on A Christie DS+60 projector.

TOOLS REQUIRED: None

Disassembly:

1. Disconnect unit from power source.
2. Remove the prime lens, if applicable, per the manufacturer instructions.

Assembly:

1. Remove the Navitar lens from lens adapter by gently rotating counter-clockwise and set aside.
2. Insert the keyed portion of the lens adapter into the projector and rotate the lens adapter clockwise.
3. Insert the lens into the lens adapter by gently turning clockwise.
4. To focus, gently twist the front of the lens. To zoom, loosen thumbscrew and twist the knurled zoom ring and re-tighten the thumbscrew. **CAUTION:** When focusing, be sure not to twist lens completely out of the adapter!

REV 03/13/06 REP

Navitar, Inc.
200 Commerce Drive
Rochester, New York
14623

Phone
585.359.4000
800.828.6778

Fax
585.359.4999

navitar.com
info@navitar.com