

## NUVIEW Installation Instructions

### Navitar/NuView Series 101 lens on Mitsubishi model FL7000 projectors.

TOOLS REQUIRED: PHILLIPS HEAD SCREW DRIVER

#### Disassembly:

1. Disconnect the unit from the power source and place projector with lens facing you. Remove six (6) screws holding the front cover of the projector in place. Remove the cover and set aside for reinstallation.
2. Remove four Phillips head screws holding prime lens in place and disconnect the power cable for the zoom/focus motor and remove the prime lens.

#### Assembly:

1. Ensure that your Navitar lens and its adapter are separate (except on MCZ275). Using the (4) Phillips head screws supplied, install the adapter correct side up into the projector.
2. Replace the front cover of the projector removed in step 1, above.
3. To focus, gently twist the front of the lens. To zoom, loosen thumbscrew and twist knurled ring (zoom lenses only, of course). Re-tighten thumbscrew. CAUTION: Do not twist entire lens out of adapter!

Navitar, Inc.  
200 Commerce Drive  
Rochester, New York  
14623

Phone  
585.359.4000  
800.828.6778

Fax  
585.359.4999

[navitar.com](http://navitar.com)  
[info@navitar.com](mailto:info@navitar.com)