

• NuVIEW Installation Instructions

• Installation of Navitar NuView Series 585 lens on Mitsubishi XD1000 • XD2000 & WD2000 projectors.

• Before installing the lens into the projector return the right/left & up/down lens shift to
• their zero positions.

• Disassembly:

- 1. If supplied with a manufacturers' prime lens, disconnect unit from power source and orientate the projector with the lens facing you. Use the manufacturers' instructions to remove the prime lens.

• Assembly:

- 1. Separate your Navitar lens and adapter by gently rotating the lens counterclockwise while holding the adapter. **DO NOT** place pressure on the lens to separate as this may result in damage to the nylon drive pin.
- 2. Insert the bayonet portion of the adapter ring into the projector so that the locating slot is on the right. Rotate the lens lock lever counter clockwise until it locks.
- 3. Replace the front cover of the projector removed in step 1, above.
- 4. Reinstall the Navitar lens into the adapter by turning clockwise into the adapter.
- 5. To focus, gently twist the front of the lens. To zoom, loosen thumbscrew and twist the knurled zoom ring. Re-tighten thumbscrew. CAUTION: When focusing, be sure not to twist lens completely out of the adapter!

• Navitar, Inc.
• 200 Commerce Drive
• Rochester, New York
• 14623

• Phone
• 585.359.4000
• 800.828.6778

• Fax
• 585.359.4999

• navitar.com
• info@navitar.com