

NuVIEW Installation Instructions

Installation of Navitar/ NuView Series 637 lens on NEC model MT860, MT1060, MT1065 & MT1075 projectors

TOOLS REQUIRED: PHILLIPS HEAD SCREWDRIVER, 2.5mm LONG ARM ALLEN WRENCH.

Disassembly:

1. Disconnect unit from power source and place projector with lens facing up. Remove two (2) screws from bottom of lens cover. Remove cover and set aside for reinstallation.
2. Remove four 3/32" hex head screws holding prime lens in place, disconnect two wire harness connectors and remove prime lens.

Assembly:

1. Separate your Navitar lens and adapter (except on MCZ275) by gently rotating the lens counterclockwise while holding the adapter. **DO NOT** place undo pressure on the lens to separate as this may result in damage to the nylon drive pin.
2. Using the four (4) fillister head screws supplied, install the adapter correct side up into the projector
3. Replace the front cover of the projector removed in step 1, above.
4. To focus, gently twist the front of lens. To zoom, loosen thumbscrew and twist knurled ring (zoom lenses only, of course). Re-tighten thumbscrew. CAUTION: Do not twist entire lens out of adapter! On MCZ275 models twist the inner knurled ring to zoom and twist the outer knurled ring to focus the lens.

Navitar, Inc.
200 Commerce Drive
Rochester, New York
14623

Phone
585.359.4000
800.828.6778

Fax
585.359.4999

navitar.com
info@navitar.com