

## NuVIEW Installation Instructions

### Installation of Navitar/ NuView Series 371 lens on Sanyo model PLV-WF10 projectors.

TOOLS REQUIRED: PHILLIPS HEAD SCREWDRIVER

#### Disassembly:

1. Disconnect unit from power source.
2. Remove four (4) screws from top cover, then remove two (2) screws from the lower cover. Remove cover and set aside for re-installation.

#### Assembly:

1. Insert keyed portion of the lens adapter into the projector and rotate lens lock lever downward while squeezing it with stationary handle.
2. Replace the top and bottom covers removed in step 2 of the disassembly procedure above.
3. To focus, gently twist the front of the lens. To zoom, loosen thumbscrew and twist the knurled zoom ring. Re-tighten thumbscrew. CAUTION: When focusing, be sure not to twist lens completely out of the adapter!

Navitar, Inc.  
200 Commerce Drive  
Rochester, New York  
14623

Phone  
585.359.4000  
800.828.6778

Fax  
585.359.4999

[navitar.com](http://navitar.com)  
[info@navitar.com](mailto:info@navitar.com)