

## NuVIEW Installation Instructions

### Installation of Navitar Series 485 lens on Sharp XG-C330, C430 & C465 projectors.

TOOLS REQUIRED: None

Disassembly:

1. Disconnect unit from power source.
2. Remove the prime lens, if applicable, per the manufacturers instructions.

Assembly:

1. Make certain that the lever at the top opening of the projector is rotated all the way counterclockwise.
2. Insert the keyed portion of the lens adapter into the projector with the small hole at 12:00 and the slot at 6:00 until it is flat against the back flange and engages the 2 pins located on the flange.
3. Hold the adapter tube in place and rotate the lever at the top of the projector as far as it will go in a clockwise direction.
4. Insert the lens into the lens adapter by gently turning clockwise.  
(485MCZ500 & 485MCL1625 only)
5. If you are using the 485MCZ275 the adapter and lens are one piece. Follow steps 1 thru 3 above to insert the lens. Focus the 485MCZ275 by twisting the outer knurled ring CW or CCW. To Zoom rotate the inner knurled ring in the same manner.
6. If you are using the 485MCL1625 focus by rotating gently CW or CCW. Move the projector location to change the zoom.
7. If you are using the 485MCZ500, to focus, gently twist the front of the lens. To zoom, loosen thumbscrew and twist the knurled zoom ring and re-tighten the thumbscrew.

**CAUTION:** When focusing, the 485MCZ500 and 485MCL1625 be sure not to twist lens completely out of the adapter!

Navitar, Inc.  
200 Commerce Drive  
Rochester, New York  
14623

Phone  
585.359.4000  
800.828.6778

Fax  
585.359.4999

[navitar.com](http://navitar.com)  
[info@navitar.com](mailto:info@navitar.com)

REV 033105 REP